





Direction of shaft rotation: Standard
When facing shaft end of motor, shaft to rotate:
Clockwise when port "A" is pressurized
Counter-clockwise when port "B" is pressurized
Note: Nut tightening torque: $500 \pm 10 \text{ Nm}$
B: Black

HGB S.R.L.

BMT Assembly drawing

BMT-630-W-T-D-B